



## Operating Instructions

863 Valley View Road, Eighty Four, PA 15330  
Tel: 724-941-9701 • [www.skcinc.com](http://www.skcinc.com)

### Cyclone Calibration Adapter Cat. No. 225-01-03

The calibration adapter is for monitoring the flow through a filter/cyclone. It is designed to fit cyclones Cat. No. 225-01-01 and 225-01-02.

Assemble the filter/cyclone assembly in the normal way and connect to the sample pump.

Moisten the O-ring inside the large end of the adapter and push onto the enlarged section of the cyclone extension. Connect the small end to a flowmeter or other calibration instrument. Use 1/4 in ID tubing to make the connection and maintain as short as possible. *(See illustration on reverse side.)*

Turn on pump and read flow from the calibrator.

#### SKC Limited Warranty and Return Policy

SKC products are subject to the SKC Limited Warranty and Return Policy, which provides SKC's sole liability and the buyer's exclusive remedy. To view the complete SKC Limited Warranty and Return Policy, go to <http://www.skcinc.com/warranty>.

